



pro.equip

---



User Guide

# TRADITIONAL RICE COOKER

ED140 / 4061031

---

Proudly Distributed By

**New Zealand**  
Southern Hospitality  
[southernhospitality.co.nz](http://southernhospitality.co.nz)  
NZBN - 9429039301956

**Australia**  
Reward Hospitality  
[rewardhospitality.com.au](http://rewardhospitality.com.au)  
ABN - 40010183669



## TABLE OF CONTENTS

|                                |   |
|--------------------------------|---|
| Overview .....                 | 4 |
| Features .....                 | 5 |
| Technical Specifications ..... | 5 |
| Operation .....                | 6 |
| Cleaning & Precautions .....   | 7 |
| Electrical Diagram .....       | 7 |
| Safety Precautions .....       | 8 |

**This instruction booklet contains important advice for operation and maintenance. Please keep the booklet in a safe place for future reference.**

## RICE COOKER OVERVIEW

Handle

Lid

Cook

Warm

Switch Button



### ACCESSORIES



Spoon



Measuring Cup

## RICE COOKER

### FEATURES

- Fully Removable stainless steel lid
- Non-stick thickened liner
- One-touch cooking
- Automatic keep warm
- Comes with spoon and measuring cup
- Convenient 10amp plug supply



### TECHNICAL DATA SPECIFICATION

|                               |                       |       |
|-------------------------------|-----------------------|-------|
| <b>DIMENSIONS</b>             | Width                 | 470mm |
|                               | Depth                 | 395mm |
|                               | Height                | 335mm |
| <b>LIQUID CAPACITY</b>        | 13L                   |       |
| <b>UNCOOKED RICE CAPACITY</b> | 3.6L                  |       |
| <b>NET WEIGHT</b>             | 5.2kg                 |       |
| <b>POWER</b>                  | 2000W / 230V, 50-60Hz |       |
|                               | 10 Amp Plug Supplied  |       |

## OPERATION—FOR COMMERCIAL USE ONLY

1. Measure the desired amount of rice using the measuring cup supplied with the rice cooker. Rinse the rice several times until the water in the bowl becomes relatively clear.
  - One cup of rice has volume of 160ml (About 140g)
  - DO NOT rinse rice in the cooking pot. Washing rice in the pot may damage the fluorine-resin coating or deform the bottom, which can result in poor heat conduction due to improper contact with the heating plate.
2. Put the washed rice into the inner pot and add water to the corresponding level (e.g., fill to level “3” if cooking 3 cups of rice). Adjust the amount of water according to your personal taste.
  - Do not add water in excess of the “MAX” water mark.
3. Wipe any water from the outside of the pot, place the pot into the cooker, and turn it slightly from left to right to ensure proper contact with the heating plate. Level the rice inside the pot.
4. Close the outer lid. Push it in securely until the lock clicks.
  - If the lid is not closed properly the cooking efficiency will be affected.
  - Make sure the lid is locked before moving the cooker.
5. When ready to cook, connect the power supply cord to the cooker first, then plug into an AC wall outlet.
  - DO NOT plug cord in until you are ready to cook.
6. Press the “Cooking” button. The rice will start to cook, and the “cook” light will turn on once the plug is inserted into the socket. You must press the “cook” button to start cooking. If the switch is not pressed, the “warm” light will turn on after 1–2 minutes, and the cooker will enter the keep-warm mode.
7. When cooking is finished. The “cooking” switch will pop up and a click will be heard. At the same time, the cooking light will go out and the keep warm light will come on.

After the cooking cycle ends, keep the lid closed for about 15 minutes to allow the rice to finish steaming and become fluffy and tasty. Once the rice is steamed, open the outer lid and stir the rice well. Serve the cooked rice immediately, or let the cooker keep it warm automatically.
8. **Food Steaming:** This Rice Cooker can be used for steaming. Please note the steam tray is not included in the accessories. Add the appropriate amount of water to the cooking pot. The amount of water depends on the type and quantity of food (DO NOT exceed the height of the steam tray). Place the steam tray into the pot and put the food on the tray. Operate the cooker according to steps 4, 5, and 6 above. When steaming is finished, turn off. The cooker will then automatically keep the food warm until serving.
9. Unplug the cord before serving.
10. Only use the spoon supplied with this cooker. Do not use a metal spoon, as it may scratch the non-stick coating.


## CLEANING

1. Wash the components of the steam valve promptly. Clean the cover and seal of the steam valve separately.
2. Dry and wipe the cover, the seat, and the inside of the steam valve with a cloth.
3. Remove the inner pot from the rice cooker. Wash it with mild detergent and rinse with fresh water, then dry with a soft cloth.  
Do not use a metal brush or harsh tools, as they may damage the non-stick coating.
4. Remove the water holder, empty any remaining water or soup, clean it thoroughly, and reinstall it.
5. Grains of cooked rice or other debris may stick to the electric hot plate. Use fine sandpaper to gently remove them, then wipe with a soft cloth to ensure full contact between the inner pot and the heating plate.

## PRECAUTIONS

1. Remove any foreign matter from the steam valve promptly to maintain its effectiveness in preventing overflow and ensuring proper cooking.
2. When cleaning the steam valve, do not pull or push the sealing ring unnecessarily.
3. Do not heat the inner pot on any other stove or furnace, as it may easily deform.
4. When the rice enters the keep-warm mode, it is not suitable for immediate consumption. Let it steam for about 15 minutes for softer, more flavourful rice.
5. Do not keep rice in the warm mode for more than 12 hours contamination.
6. This product does not have a porridge-cooking function and should not be used to cook porridge or soup, as excess liquid may overflow and damage the heating element.

## ELECTRICAL DIAGRAM



## SAFETY PRECAUTIONS

1. This apparatus is not intended for use by persons with reduced physical capability, slow response, or mental disorders (including children), unless they are under the supervision or assistance of responsible and qualified personnel.
2. Use only a properly earthed wall socket, and ensure the plug is securely inserted. Do not use a multi-purpose socket or share the outlet with other electrical appliances at the same time.
3. If you do not use it, please pull the power cord out of the socket.
4. After inserting the power cord into the socket, ensure it is fully and firmly inserted. Otherwise, a poor connection may cause the heating element to burn out.
5. The electric rice cooker must not be placed on an unstable or wet surface, or near an open flame; otherwise, it may become damaged or malfunction.
6. When cooking, the steam vent becomes extremely hot. Do not place your face or hands near it to avoid scalding.
7. The body and lid of the electric rice cooker must not be washed with water or submerged. Doing so may damage the insulation and create a safety hazard.
8. If the power cord is damaged, it must be replaced with a new one provided by the manufacturer.
9. Do not allow children to operate. Keep it out of the reach of infants to prevent electric shock, scalding, or other dangerous accidents.



**FOR MORE INFORMATION, OR TO RE-ORDER, PLEASE CONTACT OUR DISTRIBUTORS.**

---

**New Zealand**  
Southern Hospitality  
**southernhospitality.co.nz**  
NZBN - 9429039301956

**Australia**  
Reward Hospitality  
**rewardhospitality.com.au**  
ABN - 40010183669