OD260

SKOPE Open Deck Chiller



User Manual





SKOPE Warranty Protection

Register now for peace of mind

It's quick and simple. Take a few minutes to register your SKOPE product and enjoy more efficient support plus other warranty benefits. When registering, make sure you have your cabinet serial number at hand.

To register online:

Visit our website at www.skope.com/warrantyprotection then complete and submit the online registration form.



Or freephone:

1800 121 535 (Australia) 0800 947 5673 (New Zealand)

SKOPE 1-year Extended Warranty

Extend your Warranty Protection by 1 year during registration. Please check you have not already organised an extended warranty through your dealer at time of purchase. For pricing information on an extended warranty visit www.skope.com/warrantyprotection

Service & Support

We know you will get years of satisfaction from your new SKOPE product when you follow a few simple preventative maintenance guidelines.

Helpful information is available on our website www.skope.com/serviceandsupport



Thank you for purchasing a SKOPE refrigeration product.

CONTENTS

1 Installation Installing the Shelves8 2 Operation Lights......9 Optional Night Blind......9 3 Servicing

1 Installation

Safety First Always observe safety precautions when using any electrical appliance. Read these instructions carefully and retain them for future reference.

- When the appliance is used by or near young children or infirm persons, close supervision is necessary, especially to ensure children do not play with it.
- Do not use this appliance for other than its intended use.
- Do **not** cover the grilles or block the entry or exhaust of airflow by placing objects up against the refrigeration unit.
- Do not probe any opening.
- Only use this appliance with the voltage specified on the cabinet rating label.
- Ensure the chiller has adequate ventilation as this is essential to economical, high performance.
- Be careful not to touch moving parts and hot surfaces.
- For your own safety and that of others, ensure that all electrical work is done by authorised personnel.
- If the power supply flexible cord becomes damaged, it must be replaced by an authorised service agent or similarly qualified person in order to avoid a hazard.
- Ensure all necessary safety precautions are observed during installation or removal of the refrigeration unit.
- The chiller is not designed to be stable while in motion. Use extreme caution when moving or transporting it.
- Do not store explosive substances such as aerosol cans with a flammable propellant in this appliance.
- Please contact SKOPE Customer Services for advice regarding disposal of this appliance.

WARNING

Disconnect the cabinet from the mains power supply before attempting any cleaning or maintenance.

CAUTION

Never overload the power supply, which could damage the chiller and product. See the rating label inside the cabinet for the safe power supply and current draw.

CAUTION

Do **NOT** allow liquids or any other materials to drain into the bottom of the cabinet, as this could lead to refrigeration system failure.

______ Installation

Positioning the Cabinet

Climate Class The chiller is designed to operate within a climate class 3 environment (25°C @ 60% RH). We recommend that you put the chiller in the coolest place possible because it will use less power and last longer.

Chiller The location of the chiller may be the single most important decision that will Location extend its life and ensure economical, high performance. Ensure the cabinet sits on a level surface to prevent the condensate tray from overflowing.

Air Movement The cabinet must NOT be situated where it is affected by air-conditioning air outlets, ventilation fans or air re-circulation fans, or draughts from doorways, as this will compromise the airflow and thus product temperature in the open cabinet zone.

> There must be NO air movement directly into the cabinet opening. Air movement will cause failure of the air curtain over the product, resulting in excessive temperature rise. Detectable air draft will adversely effect the cabinet operation. Maximum air movement across the cabinet opening must not exceed 0.2 m/s.

IMPORTANT

There must be **NO** air movement directly into the cabinet opening.

Power Cord The chiller is supplied with a flexible power cord fitted with a 3-pin plug, which is packed separately inside the cabinet. Connect the power cord to the IEC socket on the back of the cabinet before moving into position.

Ventilation Adequate ventilation must be provided around the refrigeration unit and cabinet at all times. Refrigeration exhaust air must not be restricted, and must be able to easily flow out and away from the cabinet.

> Ensure there is unimpeded clearance in front of the kick panel at all times. Never store cardboard cartons or other items in the front or rear of the refrigeration unit.

CAUTION

Ensure adequate ventilation clearance around the refrigeration unit and cabinet.


Determine if the installation is free-standing or enclosed, and ensure the installation meets the ventilation requirements detailed below.

Free-standing installations

Free-standing cabinets must be installed with the following minimum clearances (also see diagrams over page):

- 30mm behind (provided by the rear spacers on the back of the cabinet).
- 60mm on either side of the cabinet.
- 500mm above the cabinet.

If these clearances can't be met, the installation should be treated as an enclosed installation.




Free-standing installation ventilation requirements

Enclosed installations

Enclosed installations must have the following minimum clearances around the cabinet, and include the following features:

- 75mm behind the cabinet.
- An air guide must be used to ensure all refrigeration exhaust air is directed up and away from the cabinet.
- The air guide must also ensure the air exhaust outlet cannot be blocked by product or other items above the cabinet.


Refrigeration exhaust air must **NOT** be allowed to run horizontally across the top of the cabinet, as it may be pulled down into the cabinet interior.



Enclosed installation ventilation requirements

6 ______ User Manual


Stabiliser Feet Ensure the stabiliser feet are wound all the way up when moving the chiller around. Once the chiller is in position, wind down the two front stabiliser feet to firmly contact the ground.



Shelves

Installing the The chiller is supplied with three metal shelves. The shelves are different Shelves depths, with the top shelf being the shallowest and the bottom shelf the deepest. The bottom shelf is angled and fixed in position. The two top shelves are height and angle adjustable, and removable.


> The two top shelves are each held in place by cantilevered shelf brackets which clip into cut-outs in the cabinet back duct. These brackets may be in one part or two parts. The two part version allows for additional 6mm interval height adjustments by separating the shelf bracket into two and re-slotting together using the alternative slots.



To fit the shelves


1. Clip the cantilevered shelf brackets into the slots in the cabinet back duct.

> Use the different positions on the bracket to set the shelf angled or level (see image above).



Sit the corresponding metal shelf on the cantilevered brackets ensuring the back of the shelf clips over the rear of the brackets.

3. Push the cantilevered brackets outwards until they clip into the edge locating slots on the side of the shelf.



Automatic Start-Up

After the cabinet has been positioned in a suitable place, plug it in and check the following activity.

Item	Activity	
Electronic controller	An electronic controller runs the chiller and is visible behind the front panel. The display panel first flashes start-up messages before stabilising on the cabinet temperature.	
Lighting	The lights that illuminate the cabinet interior will come on approximately two seconds after the chiller is turned on.	
Refrigeration unit	The refrigeration unit evaporator and condenser fans should all operate continuously from the time the cabinet is plugged in. This may be verified by checking for air movement inside the cabinet. The internal cabinet air will continue to circulate at all times.	
	The compressor will start after approximately one minute, will switch off when the cabinet internal temperature reaches approximately +1.5°C and on again at approximately +4°C.	

Lights

The chiller is fitted with two LED side lights. The lights can be manually switched on and off using the light button on the electronic controller faceplate (see page 11).

Lighting components must not be tampered with in any way. If a unit is suspected of being faulty, a service call should be arranged so that a replacement component can be fitted.

Optional Night Blind

The chiller may be fitted with a night blind which should be pulled down into the closed position during store closing hours to save power.

The night blind is located behind the sign panel and is not visible when in the open position.

To close the night blind, use the handle to pull the blind down and hook it under the night blind retaining brackets at the bottom of the chiller opening. To open, use the handle to release the blind from the retaining brackets and control the blind as it opens.

Loading Product

Let the chiller run for 30 minutes before loading it with product for the first time. When loading the cabinet shelves with product:

- Allow adequate air space around each item to ensure even cooling and efficient operation of the chiller.
- Remove some product if the shelves are flexing.
- Do not exceed a maximum load of 20kg per shelf.
- Do not load product over the return air grille.

10 Operation

Electronic Controller

Introduction The chiller is fitted with a Carel S4 Evo electronic controller which is visible through a cutout in the cabinet front panel. The electronic controller is preprogrammed and requires no initial setup or additional programming. SKOPE does not recommend that the settings be changed unless absolutely necessary.

> To achieve energy efficient operation, the electronic controller uses temperature probes to control and display the chiller temperature, collect data, signal temperature alarms and force a defrost cycle when required.

Faceplate Because the electronic controller plays such an important role, it's helpful to know the parts of the faceplate you may use.



No.	Item	Description
1	888	Digital display of cabinet temperature or messages. The temperature is what the sensor inside the chiller detects, and not necessarily the product temperature. However, they may be very close depending on how the controller is set to sense temperature.
2	ES	Up: Button. Used for programming.
3	mu _{to}	Mute (set): Button. Press to mute the alarm. Press and hold to access parameters.
4	▼ = (m)=	Light (down): Button. Press to switch the cabinet interior light on and off.
5	***	Defrost: Indicator. ON when the defrost is activated. Flashes when the activation of the defrost is temporarily delayed due to procedures in progress.
6	0	Compressor: Indicator. ON when the compressor and condenser fan starts. Flashes when activation of the compressor is temporarily delayed.
7	K	Fan: Indicator. ON when the internal cabinet fans are activated. Flashes when activation of the fans is temporarily delayed.
8	•	Alarm: Indicator. ON when alarm is signalled.

Lights Press the Light button on the electronic controller faceplate to manually switch the cabinet light on and off.

Temperature The chiller temperature setpoint is factory set at 2.0°C, and can be adjusted **Setpoint** between 0.0°C and 4.0°C for other specialist applications if required (see below).

> SKOPE do not recommend that the setpoint be changed unless it is absolutely necessary, and then only by small increments at a time.

To view and adjust the temperature setpoint

1. Press and hold the **set** button for 3 seconds until **PS** is shown on the display, indicating entry into the controller settings menu.



2. Press the *up* or *down* button to scroll the menu until **St** is shown on the display.



- 3. Press the **set** button. The current setpoint value is shown on the display.
- Press the *up* or *down* button to increase or decease the setpoint value to the required temperature.
- 5. Press the **set** button to temporarily save the setpoint value.
- Press and hold the **set** button for 3 seconds to permanently save the setpoint value and exit the controller settings menu.

Operation User Manual

Messages and The following table explains messages and alarms that the electronic Alarms controller displays.

Messages

Display	olay Description						
20	The chiller is in 'Normal' mode and the electronic controller displays the chiller temperature.						
EEP	The chiller is in Cold Climate Protection mode. The chiller enters cold climate protection mode if the room ambient temperature gets too cold. The lights remain on and cannot be switched off.						
Alarms							
<u> </u>							
<u> </u>	Probe fault. An alarm sounds. Contact a service agent.						
<i>E2</i>							
LO	Low temperature alarm. An alarm sounds. The temperature inside the chiller is too cold and an alarm sounds. The controller will automatically reset the alarm once the temperature inside the chiller raises.						
H;	High temperature alarm. An alarm sounds. The temperature inside the chiller is too warm and an alarm sounds. The controller will automatically reset the alarm once the temperature inside the chiller drops.						
cht	Refrigeration system high temperature Pre-warning (auto reset)	Check refrigeration ventilation and ensure the cabinet is installed in a suitable environment (see page 5).					
[HE	Refrigeration system high temperature Shutdown (manual reset)	To reset the 'CHt' alarm - unplug the cabinet from the power supply for 1 minute, then reconnect to power supply.					
		If alarm persists, contact a service agent.					
ELO	Low voltage alarm. An alarm sounds. The mains voltage is low. An alarm sounds and the controller switches off the compressor. The controller will automatically reset the alarm once the mains voltage raises.						
EHI	High voltage alarm. An alarm sounds. The mains voltage is high. An alarm sounds and the controller switches off the compressor. The controller will automatically reset the alarm once the mains voltage drops.						
	Electronic controller fault. Contact a service agent.						
EF	Electronic controller rault. Contract a Service agent.						

3 Servicing

Isolating Electrics

The chiller should be isolated from the power supply before attempting **any** maintenance. Unplug the cabinet from the power supply to isolate.

Lighting

The cabinet is fitted with two LED strip side lights. If a light is suspected of being faulty, a service call should be arranged so that a replacement light can be fitted.

Cleaning

Cabinet Ensure the cabinet is disconnected from the mains power supply before cleaning the cabinet.

When necessary, wipe both the interior and exterior of the cabinet with warm soapy water and a soft cloth. Do **not** use chemical cleaners.

CAUTION

Do **NOT** wash any liquid down into the refrigeration system, as this could lead to refrigeration failure.

Condenser To ensure trouble-free performance, the condenser coil must be kept clean. Coil We strongly urge monthly cleaning with a soft brush to remove dust and fluff. A thorough cleaning is required by qualified service personnel every six months. The condenser coil must be kept clean for efficient and reliable operation.


WARNING

Disconnect the chiller from the power supply before cleaning the condenser coil.


To clean the condenser coil

1. Disconnect the cabinet from the power supply.

2. Remove the front panel from the cabinet by undoing the fixing screws near the bottom of the panel and lifting it up and off the cabinet.



3. Brush the condenser coil with a soft brush



4. Refit the front panel and reconnect to the power supply.

Troubleshooting

For questions about the electronic controller, see page 11. For problems with the cabinet and refrigeration cassette, use the following table.

Problem	Possible Cause	Suggestions
Chiller not operating No controller display	Loss of power supply	Check mains power supply.
Lights not on	Light switched off	Switch the light on with the light button on the electronic controller faceplate (see page 11).
	Lighting fault	Arrange a service call.
	Blown cabinet fuse	Arrange a service call.
Power consumption is higher than expected	Refrigeration unit operating too hot	 Clean the condenser coil (see page 15). Ensure the cabinet has good ventilation around the refrigeration unit (see page 5). Ensure the cabinet is installed in a cool location within operating specifications (see page 5).
Product is too warm	Restricted airflow to cabinet	Ensure product is not blocking airflow slots. Ensure there is space around individual product pieces.
Warm cabinet temperatures	Blocked condenser	Clean the condenser coil (see page 15).
Compressor operating for long periods (more than 1 hour)	Poor ventilation around refrigeration cassette	Ensure the cabinet is installed in a cool location within operating specifications (see page 5).

Servicing 16

SKOPE Industries Limited

A.B.N. 73 374 418 306 AU: 1800 121 535 NZ: 0800 947 5673 skope@skope.com www.skope.com

Trademark Infringement

The SKOPE and Centaur trademarks on this product are infringed if the owner, for the time being, does any of the following:

- Applies the trade mark to the product after their state, condition, get-up or packaging has been altered in any manner
- Alters, removes (including part removal) or obliterates (including part obliteration) the trade mark on the product
- Applies any other trade mark to the product
- Adds to the product any written material that is likely to damage the reputation of the trade mark

Notice of the above contractual obligations passes to:

- · Successors or assignees of the buyer
- · Future owners of the product

OD260 SKOPE Open Deck Chiller User Manual MAN80055 Rev. 1.1 Nov. 2017

© 2017 SKOPE Industries Limited. All rights reserved. SKOPE Industries Limited reserve the right to alter specifications without notice.

SIXOPE is a registered trademark of SKOPE Industries Limited.